

VERNIER TAPES

For Shopsmith Adjustable Stop Collar (555937)

.005	.010	.015	.020	.025	.030	.035	.040	.045	.050	.055	.060
------	------	------	------	------	------	------	------	------	------	------	------

1/128	1/64	3/128	1/32	5/128	3/64	7/128	1/16
-------	------	-------	------	-------	------	-------	------

How to install:

1. Print "Vernier Tapes" .pdf file on 8-1/2" x 11" paper.
2. Measure printed tapes; they should be slightly longer than 7" (7.006", to be exact).
3. If tapes are the wrong length, adjust printer or copy the printout on a reducing/enlarging copier to make it the correct size.
4. Cut tapes from printout.
5. Spray back of tapes with spray adhesive (such as 3M 77).
6. Apply tapes to top and bottom parts of stop collar.



Note the gap in the top Vernier. This lets you reach the locking Allen screw.

How to use:

1. To adjust table height in thousandths of an inch, use top tape.
2. To adjust table height in 1/128ths of an inch, use bottom tape.
3. After deciding which tape to use, choose a line on the opposite tape to serve as your indicator or reference mark.
4. Turn the collar clockwise to raise the table.
5. Turn the collar counterclockwise to lower it.
6. For more great tips like this, take a class at the Shopsmith National Woodworking Academy in Dayton, Ohio or on the Internet at HANDS ONLINE! (<http://www.shopsmithacademy.com>).



© 2007 Shopsmith Inc.