

Attach a cleat to one side of a small piece of pegboard and you have an instant drilling guide for shelf pins. Drill the first hole and insert a dowel into it to hold the jig while you drill the rest of the holes.

