

R = running winding  = capacitor
 S = starting winding  = centrifugal switch




Figure 1




Figure 3




Figure 2






Figure 4

Dual Voltage / Reversible Rotation


TO REVERSE ROTATION INVERT



Dual Voltage / Single Rotation



Single Voltage / Reversible Rotation



Single Voltage / Single Rotation

