

## How to Reset the Speed Control Dial

In order to re-calibrate the outer indicator dial it is important to remember the set screw and jam nut used to set the high speed will stop the control handle as well as the speed from traversing any further. Therefore if the control handle is removed and the outer indicator dial set at **Fast** this will give you the proper designation for your other speeds.

If it is not possible to remove the control handle at its stopping point you will then need to attach the sanding disc to turn the main spindle and slowly return the side cutout of the control handle (located around the protruding knob) to the 12:00 position relate the knob to the hands of the clock where 3:00 = **W**, 6 = **V**, etc. Several attempts may be needed in order to achieve this.

