

CAUTION

Do not turn SPEED-DIAL unless motor is running. Do not force handle. See page 2 of OWNER'S MANUAL.